

FORMED / *concrete basins*

BASIN INSTALLATION

SURFACE MOUNTED BASINS.

Position your basin in its final place on the counter top. Mark the extents of the basin on the counter.

Secure the basin using a silicone / mastic to the underside of the basin.

Fit the waste with clear excess clear silicone / mastic inside the bowl before hand tightening. DO NOT excessively tighten the waste as this can cause the basin to crack or fracture.

Carefully wipe away any excess silicone / mastic off the concrete before it dries.

WALL MOUNTED BASINS.

Measure and mark out the position of the basin on the wall using masking tape.

Measure and mark the position of the brackets onto the wall.

Please follow instructions on our bracket fitting sheet as required.

With the brackets securely fitted, position the basin onto the brackets.

Note. There is a 15mm moisture resistant board glued to the underside recess of your concrete basin.

Using 20mm screws fix through the brackets into the moisture resistant board to secure the basin.

Fit the waste with clear excess clear silicone / mastic inside the bowl before hand tightening. DO NOT excessively tighten the waste as this can cause the basin to crack or fracture.

Carefully wipe away any excess silicone / mastic off the concrete before it dries.

Seal between the wall and basin using silicone / mastic accordingly.